

Knitted Teddies and Sheep

Guidance for complying with CE marking requirements

Introduction

Every toy needs to carry a CE mark to show that it meets the essential safety requirements of the Toy Safety Directive. This includes handmade toys and toys donated for charitable purposes. So teddies and sheep knitted by Mothers' Union members to be given to children need to meet these requirements.

In brief, a knitted teddy or sheep needs to be designed and made so it is suitable for young children to play with safely. The vast majority of teddies & sheep knitted by Mothers' Union members and friends will meet these requirements. However, by complying with the Toy Safety Directive and meeting the conditions to attach the CE mark, it demonstrates that Mothers' Union knitted toys are being produced to high safety standards.

Instructions for a knitted teddy & sheep

All teddies & sheep must be made to the given instructions using the materials listed. Please do not make any modifications, such as additional decorations or adding buttons, plastic eyes, etc.

Check your teddy or sheep!

Please check your teddy or sheep for spaces either in the knitting or the seams where filling can come out – or for anything other than filling inside the toy.

Certification Slip

When giving your completed teddies or sheep for CE marking, please complete and sign a certification slip to show that you have used the approved pattern and materials (as below).

The labels for each item are available from Molly Hoyle and must be fixed to every item.

-X-X-X-X-X-X-X-X-X-X-



Number of knitted teddies and/or sheep:

These toys have been knitted to the approved Mothers' Union patterns, using the approved yarn and polyester stuffing.

Signature: Branch:
.....

Knitted Teddy Pattern

Materials

Washable double knitting wool in four colours
main colour for head and paws
trouser colour
jumper colour
scarf colour

All knitting yarn **must** meet the BS EN71-3 standard. This is not shown on knitting yarn labels. However, all knitting yarn sold by *Hobbycraft* meets this standard. *Hobbycraft* sell online (www.hobbycraft.co.uk) and have stores across Britain (www.hobbycraft.co.uk/storefinder)

Note: Avoid 'tinsel' yarns, those with attached sequins or mohair style yarns with fibres that pull off.

3mm knitting needles (UK size 11)

New polyester filling conforming to BS1425 (for cleanliness) and BS5852 (for flammability). This is also available from *Hobbycraft*.

Wool or embroidery thread

Tension

26st and 36 rows to 10cm over stocking stitch on 3mm needles

While the finished size is not important, the stitches should be close together so that when the finished toy is stuffed, the filling does not come out through gaps in the stitches.

Instructions

Cast on 10 stitches in main colour. Knit 10 rows

Change to trouser colour and knit 30 rows

Knit another leg. Then knit across both legs (20sts) and work a further 16 rows. Change to jumper colour and knit 24 rows.

Change to main colour and stocking stitch (one row knit and one row purl) for 14 cm (5 ½ inches).

Change to jumper colour. Continue the remainder of the teddy in reverse order.

Stitch down sides of head.

Make arms: with jumper colour, pick up and knit 8 stitches on each side of the neck join. (16sts). Knit 20 rows, then change to main colour and knit 10 rows for paws. Cast off.

Repeat for the other arm.

Scarf: cast on 75sts. Knit 4 rows, cast off loosely.

Weave in all loose ends. Sew up the teddy using an overcast stitch or back stitch, leaving an opening in the crutch for filling. Sew diagonal corners on the head for ears before stuffing with polyester filling. Sew up the opening.

Run a thread through the knitting to make a neck and draw it in, knot the ends and weave in the excess.

Embroider a smiley face using small stitches, (back stitch and stem stitch), and ensure all ends are firmly finished. Remember that the eyes actually come half way down the face!

Tie the scarf around teddy's neck and stitch across the back neck to fix securely. The loose ends of the scarf must not exceed 22cm (8½ inches).

Knitted Sheep Pattern

Materials

Washable double knitting yarn: approximately 8g cream colour and 4g grey colour

All knitting yarn **must** meet the BS EN71-3 standard.

(This is not shown on knitting yarn labels. However, all knitting yarn sold by *Hobbycraft* meets this standard. *Hobbycraft* sell online (www.hobbycraft.co.uk) and have stores across Britain (www.hobbycraft.co.uk/storefinder). Avoid 'tinsel' yarns, those with attached sequins or mohair style yarns with fibres that pull off.)

3mm knitting needles (UK size 11)

New polyester filling conforming to BS1425 (for cleanliness) and BS5852 (for flammability). This is also available from *Hobbycraft*.

Black Wool or embroidery thread

Tension: 26st and 36 rows to 10cm over stocking stitch on 3mm needles

While the finished size is not important, the stitches should be close together so that when the finished toy is stuffed, the filling does not come out through gaps in the stitches.

Abbreviations

T&D: break yarn leaving a long end, thread through stitches on the needles, draw up tightly and secure.

K2tog: Knit 2 stitches together

P2tog: Purl 2 stitches together

Instructions

Body (make one) With cream yarn, cast on 15 stitches and knit 2 rows.

Next row: increase in every stitch (30 sts).

Knit 37 rows

Next row: (K2 tog) to end (15 sts)

Knit 1 row. Cast off.

Head (make one) With cream yarn, cast on 14 stitches and knit 2 rows.

Next row: increase in every stitch (28 sts)

Knit 4 rows.

Change to grey yarn and purl 1 row.

Next row: (K2 K2tog) to end (21 sts)

Purl 1 row.

Next row: (K1 K2tog) to end (14 sts)

Purl 1 row.

Next row: (K2tog) to end (7 sts).

T&D.

Legs (make four) With grey yarn, cast on 10 stitches and work 9 rows in stocking stitch (one row knit and one row purl).

Next row: (P2tog) to end (5 sts)

T&D

Ears (make two) With grey yarn, cast on 4 stitches.

Cast off.

Tail (make one) With cream yarn, cast on 6 stitches.

Cast off.

To make up:

Fold body in half and stitch, joining the cast on and cast off edges and one end of the body.

Stuff firmly, then join the opening.

Join the head seam, leaving the cast on edge open. Stuff firmly, position and sew onto body.

Join the leg seams, leaving cast on edges open. Stuff firmly, then sew in place.

Sew ears to the side of the head and embroider eyes with black yarn.

Attach tail to the back of the sheep.